## Seat Innovation

# Alutech 500/600 Series/OP600 User Manual

### **USER MANUAL** ALUTECH 500/600 SERIES/OP600

#### **ARMREST ADJUSTMENT** UP AND DOWN

To adjust the height of the armrest loosen the adjustment wheel/ clip. Hold firmly under the armrest base and

**ALUTECH** 500 SERIES **ALUTECH** 600 SERIES

lift up or press down to desired position. There is an indicator on the base to assure correct height on both sides.


#### **ARMREST ROTATION**

Flip the armrest backwards if more space is required.



**ALUTECH** 500 SERIES





Use the pump mechanism to adjust the lumbar support. The pump can be easily reached when user is seated.


#### **DECKRAIL MOVEMENT**

Lift the lever gently to release the break from the deckrail.

Please ensure to push the lever back to lock the seat into position. The chair should always be locked on the rail to avoid injury.

#### **BACKREST ADJUSTMENT**

Lift the lever gently onto recline the seat into the desired position. The maximum reclining angle varies, depending on the type of Alutech 500 delivered.



#### LOGO

Seat

Innovation

Option to have customer logo stitched to the back or front of the chair seats.

#### **CHAIR ROTATION**

Push lever forward to rotate the seat. It is recommended to lock the seat in the desired position by firmly pulling the lever backwards until the chair is fixed.

#### **HEIGHT ADJUSTMENT**

Lift the lever gently to adjust the sitting height of the chair.

The function is operated by gas struts, so please leave the chair when raising the height, but remain seated when lowering the height.

#### **FOOTREST ADJUSTMENT**

Lift the lever gently and press footrest down to extend space for legs or let the gas strut lift it into the desired position.

Manually rotate the footrest up and down.

#### MANUALS/TOOLKIT

Toolkit, installation and user manuals are inserted under the footrest and included for each chair delivered.

For more detailed information please refer

to installation and user manuals that follow every chair delivered.

Please maintain the seat upholstery with mild detergents or as recommended.